

CHARGING SYSTEM

	Page
CHARGING SYSTEM CIRCUIT.....	11-2
ON-VEHICLE INSPECTION	11-3
ALTERNATOR	
DISASSEMBLY	11-8
INSPECTION AND REPAIR.....	11-11
ASSEMBLY	11-14
ALTERNATOR REGULATOR	
INSPECTION AND ADJUSTMENT	11-19

CHARGING SYSTEM CIRCUIT

Fig. 11-1




Fig. 11-2




Fig. 11-3




Fig. 11-4




Fig. 11-5





Fig. 11-6

**ON-VEHICLE INSPECTION**

Inspect system components as follows.

1. Drive belt tension (at 10 kg)
8–12 mm (0.32–0.47 in)

2. Fuses


Engine fuse	15A
Heater fuse	20A

3. Installed condition of wiring for alternator and regulator.

4. Battery terminal and fusible link


Loose
Corroded
Burnt

Fig. 11-7




5. Alternator on-vehicle condition
Abnormal noise from alternator when engine is running.

Fig. 11-8



6. Specific gravity 1.25-1.27


Fig. 11-9



PERFORMANCE TEST USING VOLT-METER AND AMMETER

Connect voltmeter and ammeter as illustrated, and switch off all accessory parts.


Fig. 11-10



No-load Performance test


Regulated voltage	13.8 ~ 14.8 V
Current	Less than 10 A
Engine speed	Idling to 2000 rpm.

Fig. 11-11

**Load Performance test**

1. Crank the engine with ignition coil high tension cord disconnected for about 5 to 10 seconds.
2. Turn on headlights and accessories.


Fig. 11-12



3. Start engine, and run it at approximately 2000 rpm.

Regulated voltage	12 V
Current	More than 30 A


Fig. 11-13

**PERFORMANCE TEST BY ALTERNATOR CHECKER**

1. Unplug the alternator regulator connector and plug in the checker connector.

Push "20V" switch.

Fig. 11-14




2. Check "B" terminal voltage.

Push "B" switch.

Raise engine speed from idling to 2000 rpm.


Standard voltage 13.8 to 14.8 V

Fig. 11-15




3. Check "F" terminal voltage.
Push "F" switch.
Gradually raise engine speed. The checker reading should gradually decrease from 12 volt to 3 volt.

Fig. 11-16



4. Check "N" terminal voltage.
Push "N" switch.
Maintain engine speed at approx. 1500 rpm. The pointer should be at a half of "B" terminal voltage.


Fig. 11-17



ALTERNATOR INSPECTION


1. Negative side rectifier short test.
Connect an ohmmeter (-) lead to N terminal and (+) lead to E terminal.
Meter should indicate infinity.

Fig. 11-18




2. Positive side rectifier short test.
Connect an ohmmeter (-) lead to B terminal and (+) lead to N terminal.
Meter should indicate infinity.

Fig. 11-19



3. Check rotor coil resistance.
Resistance 5-9 Ω


Fig. 11-20



4. Turn ignition switch to ON position, and check if there is battery voltage at F terminal. If not, check ENGINE fuse.

ALTERNATOR**DISASSEMBLY**

Disassemble in numerical order.

Fig. 11-21

- 1 Drive End Frame Assembly
- 2 Pulley and Fan
- 3 Rotor
- 4 Rear Bearing
- 5 Front Bearing

Fig. 11-22





Fig. 11-26


- 6 Stator Coil and Rectifier Holder
- 7 Brush Holder and Rectifier Holder
- 8 Brush Holder

Fig. 11-23




Pry drive end frame from stator.
Do not pry coil wires.

Fig. 11-24




Remove rotor from drive end frame using a press.

Fig. 11-25



Remove rotor shaft rear bearing using SST [09286-46011].

Fig. 11-26



Remove brush holder assembly using a 10 mm socket wrench and vise.

Fig. 11-27




Fig. 11-28




Fig. 11-29





Fig. 11-30



INSPECTION AND REPAIR

Rotor

1. Open circuit test
Standard resistance 4.1-4.3Ω



2. Ground test
Meter should indicate infinity.




3. Check slip ring for being dirty or burnt.



- Bearing
Check bearing for wear or roughness.




Fig. 11-31

**Stator**


1. Open circuit test
Test all four leads for continuity.

Fig. 11-32



2. Ground test
Meter should indicate infinity.


Fig. 11-33

**Brush and Brush Holder**

Check exposed brush length.

Minimum exposed length
**5.5 mm
(0.22 in)**


Fig. 11-34



When replacing brushes, assemble them as shown.


Exposed length
**12.5 mm
(0.49 in)**

Fig. 11-35

**Rectifier**


1. Rectifier holder positive side
Connect an ohmmeter (+) lead to the rectifier holder, and the (-) lead of the meter to the rectifier terminal. If there is no continuity, rectifier assembly must be replaced.

Fig. 11-36




2. Reverse polarity of test leads and check again. If there is continuity, rectifier assembly must be replaced.

Fig. 11-37



3. Rectifier holder negative side
Connect an ohmmeter (+) lead to the rectifier terminal, and the (-) lead of the meter to the rectifier holder. If there is no continuity, rectifier assembly must be replaced.


Fig. 11-38




4. Reverse polarity of test leads and check again. If there is continuity, rectifier assembly must be replaced.

ASSEMBLY


Assemble in numerical order.

Fig. 11-39

1
Fig. 11-41
Fig. 11-42





2
Fig. 11-43



3
Fig. 11-44
Fig. 11-45
Fig. 11-46


- 1 Brush Holder
- 2 Brush Holder and Rectifier Holder
- 3 Stator Coil and Rectifier Holder

Fig. 11-40




- 4 Rear Bearing
- 5 Front Bearing
- 6 Rotor
- 7 Pulley and Fan
- 8 Drive End Frame Assembly

Fig. 11-41




Insert insulator between positive rectifier holder and brush holder.

Fig. 11-42




Install brush holder onto rectifier holder using socket wrench and a vise.

Fig. 11-43




Connect stator coil "N" lead onto brush holder terminal, and solder each stator lead and rectifier lead to positive rectifier.

Fig. 11-44




Assemble rear end frame and rectifier holder with insulators.

Fig. 11-45



Assemble rear end cover with insulators.

Fig. 11-46




If there is danger of stator coil terminal wiring contacting on frame or rotor, correct by bending wiring.

Fig. 11-47



Install rear bearing facing its sealed side forward.

Fig. 11-48




Press rear bearing onto rotor shaft, using a press.

Fig. 11-49




Install the front bearing facing its sealed side rearward.

Fig. 11-50



Press drive end frame assembly onto rotor shaft, using SST [09325-12010].


Fig. 11-51



Tighten nut to specified torque.

Torque 5 – 6.5 kg-m (36 – 47 ft-lb)

Fig. 11-52



Push in brushes and temporarily lock in place with wire inserted through access hole in end frame.

Position lead wires to clear rotor.

ALTERNATOR REGULATOR

Fig. 11-53






Fig. 11-54

**INSPECTION AND ADJUSTMENT**


Check connector fitting condition before inspecting regulator.

Fig. 11-55




Always be sure to have the regulator connector pulled out when inspecting and adjusting.

Fig. 11-56



Inspect each point surface for burn or excessive damage. Replace if defective.

Fig. 11-57




Voltage adjustment

To adjust, bend the voltage regulator adjusting arm.

Regulated voltage **13.8-14.8V**

Fig. 11-58




Resistance measurement between terminals.

IG-F

Voltage Regulator	At rest	0Ω
	Pulled in approx.	11Ω


Fig. 11-59



L-E

Voltage Relay	At rest	0Ω
	Pulled in approx.	100Ω


Fig. 11-60



B-E

Voltage Relay	At rest	infinity
	Pulled in	approx. 100Ω


Fig. 11-61



B-L

Voltage Relay	At rest	infinity
	Pulled in	0Ω

Fig. 11-62



N-E

approx. 25Ω

MEMO
