

# STARTING SYSTEM

	Page
CONVENTIONAL TYPE	
STARTING SYSTEM CIRCUIT.....	7-2
PERFORMANCE TEST .....	7-2
CONVENTIONAL TYPE STARTER .....	7-5
REDUCTION TYPE	
STARTING SYSTEM CIRCUIT.....	7-19
PERFORMANCE TEST.....	7-19
REDUCTION TYPE STARTER .....	7-21

## CONVENTIONAL TYPE STARTING SYSTEM CIRCUIT

Fig. 7-1





Fig. 7-2



## PERFORMANCE TEST



## NO-LOAD PERFORMANCE TEST

Secure the starter in a vise to prevent an accident.

1. Connect the starter to a battery as is shown in the figure.

Positive side


Battery (+) → Ammeter (+)

Ammeter (−) → Terminal 30

Negative side

Battery (−) → Starter body

Fig. 7-3



2. Connect terminal 50.  
If the starter shows smooth and steady rotation with the pinion jumping out and drawing less than specified current, it is satisfactory.

## Specified current:

0.6 kw Less than 55 A at 11V


0.8 kw Less than 50 A at 11V

## TEST MAGNETIC SWITCH

— Caution —

1. Each test must be performed within 3 – 5 seconds to prevent the coil from burning out.
2. Disconnect the C terminal.

Fig. 7-4



1. Pull-in test  
Connect the magnetic switch to a battery as is shown in the figure.

Negative side


Battery  $\ominus$  —————> Starter body and terminal C

Positive side

Battery  $\oplus$  —————> Terminal 50


If the pinion has protruded, the pull-in coil is satisfactory.

Fig. 7-5




2. Hold-in test  
Disconnect terminal C. The pinion should remain protruded.

Fig. 7-6




3. Check the plunger return.  
When disconnecting the switch body, the pinion should return quickly.

Fig. 7-7



4. Check pinion clearance.
- (1) Connect the field coil lead to terminal C.
  - (2) Connect the magnetic switch to a battery as is shown in the figure.
- Positive side
- Battery (+) → Terminal 50
- Battery (−) → Starter body

Fig. 7-8



- (3) Move the pinion to the armature side to eliminate slack, and check the clearance between the pinion end and the stop collar.

**Clearance:**

**STD** 0.1 – 4.0 mm  
(0.004 – 0.157 in.)


## CONVENTIONAL TYPE STARTER

## DISASSEMBLY

Disassemble the parts in the numerical order shown in the figure.

Fig. 7-9

0.6 kw Type




1. Magnetic Switch
2. Bearing Cover
3. Lock Plate, Spring & Rubber
4. Bolt
5. Commutator End Frame
6. Yoke with Brush Holder
7. Plate & Rubber

8. Drive Lever Bolt
9. Armature
10. Drive Lever
11. Snap Ring
12. Stop Collar
13. Clutch with Pinion Gear
14. Brush Holder

Disassemble the parts in the numerical order shown in the figure.

Fig. 7-10


## 0.8 kw Type



1. Terminal Cover
2. Magnetic Switch Set Nut
3. Magnetic Switch Assembly
4. Bearing Cover
5. Lock Plate, Spring & Rubber
6. Bolt
7. Commutator End Frame

8. Yoke with Brush Holder
9. Drive Lever
10. Armature
11. Drive Housing
12. Snap Ring
13. Stop Collar
14. Clutch with Pinion Gear

Fig. 7-11



Check the armature shaft thrust clearance.

**Thrust clearance limit: 1.0 mm  
(0.039 in.)**

Fig. 7-12




Tap in the stop collar with a screwdriver.

Fig. 7-13



Pry off the snap ring with a screwdriver.

Fig. 7-14



If the pinion was difficult to pull out, smoothen shaft with an oil stone.

Fig. 7-15




Fig. 7-16




Fig. 7-17





Fig. 7-18

**INSPECTION & REPAIR****Armature Shaft & Bearing (0.6 kw Type)**

1. Inspect the armature shaft end, drive housing bushing and end frame bushing for wear or damage.

**Oil clearance: Limit 0.2 mm (0.008 in.)**



2. Bushing replacement.
  - (1) Pry out the bushing cover and press out the bushing.
  - (2) Align the bushing hole with the housing groove and press in the new bushing.

- (3) Ream the bushing to obtain the specified clearance.

**Oil clearance:**


**STD 0.035 – 0.077 mm (0.0014 – 0.0030 in.)**



- (4) Clean the bore, and install a new bushing cover.




Fig. 7-19

**Commutator**

Check for the following and repair or replace.

1. Dirty or burnt surface.  
Correct with sandpaper or a lathe if necessary.

Fig. 7-20




2. Depth of segment mica.

**Mica depth:**


<b>STD</b>	<b>0.4 – 0.8 mm</b> <b>(0.016 – 0.031 in.)</b>
<b>Limit</b>	<b>0.2 mm</b> <b>(0.008 in.)</b>

Fig. 7-21



3. If the mica depth is below the limit, correct with a hacksaw blade.

Fig. 7-22




4. Smooth out the edge with a hacksaw blade.

Fig. 7-23



5. Use #400 sandpaper to remove any chips.


Fig. 7-24



6. Runout: Correct on a lathe if it exceeds the limit.

**Runout:**  
**Limit**      **0.3 mm**  
                  **(0.012 in.)**

Fig. 7-25




7. Surface wear: If below the limit, replace the armature.

**Commutator outer diameter:**

<b>STD</b>	<b>0.6 kw</b>	<b>32.7 mm</b> <b>(1.287 in.)</b>
	<b>0.8 kw</b>	<b>28.0 mm</b> <b>(1.102 in.)</b>
<b>Limit</b>	<b>0.6 kw</b>	<b>31.0 mm</b> <b>(1.220 in.)</b>
	<b>0.8 kw</b>	<b>27.0 mm</b> <b>(1.063 in.)</b>


Fig. 7-26



### Armature Coil


1. Ground test  
Check the commutator and armature coil core. If there is continuity, the armature is grounded and must be replaced.

Fig. 7-27




2. Short circuit test  
Place the armature on an armature tester and hold a hacksaw blade against the armature core while turning the armature. If the hacksaw blade is attracted or vibrates, there is a short circuit in the armature and it must be replaced.

Fig. 7-28



3. Solder condition  
Check for continuity between the commutator and armature coil.


Fig. 7-29



### Field Coil


1. Open circuit test  
Check the field coil for continuity between the lead wire. If there is no continuity, there is an open circuit in the field coil, and it should be replaced.

Fig. 7-30



2. Ground test  
Check for continuity between the field coil end and field frame.  
If there is continuity, replace the field coil.

Fig. 7-31


**Brush**

Measure the brush length and replace if below the limit.

**Brush length:**

STD	0.6 kw	19 mm (0.75 in.)
	0.8 kw	16 mm (0.63 in.)
Limit		10 mm (0.39 in.)

Fig. 7-32

**Brush Spring**

Measure the brush spring load with a pull scale. If the reading is below standard, replace the spring.


**Tension:**

0.6 kw	1.05 – 1.35 kg (2.3 – 2.9 lb)
	0.8 kw 1.02 – 1.38 kg (2.2 – 3.0 lb)

**— Note —**


Take the pull scale reading at the very instant the brush spring separates from the brush.

Fig. 7-33

**Brush Holder**


Check insulation between the  $\ominus$  brush holder and  $\oplus$  brush holder. Repair or replace if continuity is indicated.

Fig. 7-34

**Drive Lever**


Check the drive lever and spring for wear. Replace if necessary.

Fig. 7-35

**Starter Clutch & Pinion Gear**


1. Check the spline teeth for wear or damage. Replace if necessary.
2. Check the pinion for smooth movement.

Fig. 7-36




3. Check the pinion gear teeth and chamfer for wear or damage.

Fig. 7-37




4. Rotate the pinion. It should turn free in clockwise direction and lock when turned counterclockwise.

Fig. 7-38

**Magnetic Switch**


1. Push in the plunger and release it. The plunger should return quickly to its original position.

Fig. 7-39



2. Pull-in coil open circuit test  
Check for continuity between terminal 50 and terminal C.

Fig. 7-40




3. Hold-in coil open circuit test  
Check for continuity between terminal 50 and switch body.

## ASSEMBLY

Assemble the parts in the numerical order shown in the figure.

Fig. 7-41

0.6 kw Type




1. Armature
2. Clutch with Pinion Gear
3. Stop Collar
4. Snap Ring
5. Yoke with Brush Holder
6. Drive Lever
7. Drive Lever Bolt

8. Plate & Rubber
9. Commutator End Frame
10. Bolt
11. Lock Plate, Spring & Rubber
12. Bearing Cover
13. Magnetic Switch

Assemble the parts in the numerical order shown in the figure.

Fig. 7-42


## 0.8 kw Type



- |                            |                                 |
|----------------------------|---------------------------------|
| 1. Armature                | 8. Commutator End Frame         |
| 2. Clutch with Pinion Gear | 9. Bolt                         |
| 3. Stop Collar             | 10. Lock Plate, Spring & Rubber |
| 4. Snap Ring               | 11. Bearing Cover               |
| 5. Yoke with Brush Holder  | 12. Magnetic Switch Assembly    |
| 6. Drive Housing           | 13. Magnetic Switch Set Nut     |
| 7. Drive Lever             | 14. Terminal Cover              |




Fig. 7-43




Compress the snap ring with a vise and confirm that it fits properly.

Fig. 7-44




Tap the stop collar onto the snap ring.

Fig. 7-45




Assemble the brushes, being careful not to damage them.

Fig. 7-46




Assemble the drive lever in the direction shown in the figure.

Fig. 7-47



Assemble the drive lever in the direction shown in the figure.

Fig. 7-48




Install the lock plate and measure the armature shaft thrust clearance. If clearance exceeds the specified value, correct by increasing the number of shims.

**Thrust clearance:** 0.05 – 1.0 mm  
(0.0020 – 0.039 in.)

**Adjusting shim thickness:**  
0.5 mm  
(0.020 in.)

Fig. 7-49



Check the pinion clearance.

Connect the field coil lead to terminal C.


Connect the magnetic switch to a battery as is shown in the figure.

Positive side

Battery (+) —————> Terminal 50

Battery (–) —————> Starter body

Fig. 7-50



Move the pinion to the armature side to eliminate the slack, and check the clearance between the pinion end and stop collar.

**Clearance:**  
**STD** 0.1 – 4.0 mm  
(0.004 – 0.157 in.)

## REDUCTION TYPE STARTING SYSTEM CIRCUIT

Fig. 7-51





Fig. 7-52



## PERFORMANCE TEST

## NO-LOAD PERFORMANCE TEST

1. Secure the starter in a vise to prevent an accident.
2. Connect the starter to a battery as is shown in the figure.

Positive side


Battery (+) → Ammeter (+)

Ammeter (−) → Terminal 30

Negative side

Battery (−) → Starter housing

Fig. 7-53



3. Connect the positive wire to terminal 50. If the starter shows smooth and steady rotation with the pinion jumping out and drawing less than specified current, it is satisfactory.


**Specified current:** Less than 90 A  
at 11.5V

## MAGNETIC SWITCH TEST

## — Caution —


1. Each test must be performed within 3 – 5 seconds to prevent the coil from burning out.
2. Disconnect terminal C.

Fig. 7-54




1. Pull-in coil test  
Connect the magnetic switch to a battery as is shown in the figure. The pinion should jump out.  
Negative side  
Battery (-) → Starter housing and C terminal  
Positive side  
Battery (+) → Terminal 50

Fig. 7-55



2. Hold-in coil test  
With the same connections as in the pull-in coil test, disconnect terminal C.  
At this time, the pinion should remain protruded.


Fig. 7-56



3. Check the pinion return.  
When disconnecting the cable from the starter housing, the protruding pinion should return quickly.


**REDUCTION TYPE STARTER****DISASSEMBLY**

Disassemble the parts in the numerical order shown in the figure.

**Fig. 7-57**


- |                        |                          |
|------------------------|--------------------------|
| 1. Through Bolt        | 8. Plunger Return Spring |
| 2. Field Frame         | 9. Magnetic Switch       |
| 3. Felt Seal           | 10. End Cover            |
| 4. Bolt                | 11. Armature             |
| 5. Starter Housing     | 12. Field Frame          |
| 6. Clutch & Idler Gear | 13. Brush Holder         |
| 7. Steel Ball          |                          |

Fig. 7-58




Disconnect the lead wires from the magnetic switch.

Fig. 7-59




Remove the starter housing together with the idler gear and clutch.

Fig. 7-60



Using a magnet, remove the steel ball from the clutch shaft hole.

Fig. 7-61




Lift up the brush spring and pull out the brush from the brush holder.

— Caution —

Use care not to damage the brush and commutator. Also avoid getting oil or grease on them.

Fig. 7-62

**INSPECTION & REPAIR**


Wipe off dirt and grease from the disassembled parts.

**Commutator**

Check for the following items, and repair or replace as necessary.

1. Dirty or burnt surface  
Correct with sandpaper or a lathe if necessary.

Fig. 7-63




2. Depth of segment mica.

**Mica depth:**

<b>STD</b>	<b>0.45 – 0.75 mm</b> <b>(0.0177 – 0.0295 in.)</b>
<b>Limit</b>	<b>0.2 mm</b> <b>(0.008 in.)</b>

Fig. 7-64




3. If the mica depth is below the limit, correct with a hacksaw blade.
4. Smooth out the edge with a backsaw blade.

Fig. 7-65



5. Use #400 sandpaper to remove chips.


Fig. 7-66



6. Runout: Correct on a lathe if it exceeds the limit.

**Runout:**  
**Limit**    **0.2 mm**  
               **(0.008 in.)**


Fig. 7-67



7. Surface wear: If below the limit, replace the armature.

**Diameter:**  
**STD**    **30 mm**  
               **(1.18 in.)**  
**Limit**    **29 mm**  
               **(1.14 in.)**


Fig. 7-68



### Armature Coil

1. Ground test  
 Using an armature tester or circuit tester, check the commutator and armature coil core. If there is continuity, the armature is grounded and must be replaced.


Fig. 7-69



2. Short circuit test  
 Place the armature on the armature tester and hold a hacksaw blade against the armature core while turning the armature. If the hacksaw blade is attracted or vibrates, there is a short circuit in the armature and it must be replaced.




Fig. 7-70

**3. Open circuit test**


Using the armature tester or a circuit tester, check for continuity between the segments. If there is no continuity at any test point, there is an open circuit and armature must be replaced.

Fig. 7-71

**Field Coil****1. Open circuit test**


Check for continuity between the lead wire and field coil brush lead. If there is no continuity, there is an open circuit in the field coil, and it must be replaced.

Fig. 7-72

**2. Ground test**

Check for continuity between the field coil end and field frame. If there is continuity, repair or replace the field coil.

Fig. 7-73

**Brush Holder**

Check insulation between the  $\oplus$  and  $\ominus$  brush holders. Repair or replace if continuity is indicated.

Fig. 7-74


**Brush**

Measure the brush length and replace if below the limit.

**Brush length:**

<b>STD</b>	<b>13.5 mm</b> <b>(0.531 in.)</b>
<b>Limit</b>	<b>10 mm</b> <b>(0.39 in.)</b>

Fig. 7-75

**Brush Spring**

1. Measure the brush spring load with a pull scale. If the reading is below standard, replace the spring.

**Tension: 1.5 – 2.0 kg**  
**(3.3 – 4.4 lb)**

**— Note —**

**Take the pull scale reading at the very instant the brush spring separates from the brush.**

Fig. 7-76




Fig. 7-77

**Magnetic Switch**


1. Pull-in coil open circuit test  
Check for continuity between terminal 50 and terminal C.

Fig. 7-78




2. Hold-in coil open circuit test  
Check for continuity between terminal 50 and the magnetic switch body.

Fig. 7-79




3. Check for wear or damage.

Fig. 7-80

**Clutch**

1. Rotate the pinion. It should turn free in clockwise direction and lock when turned counterclockwise.

Fig. 7-81




2. Check the gear teeth for wear or damage. Also inspect the flywheel ring gear for same.

Fig. 7-82

**Gear**


Check the gears for wear or damage.

Fig. 7-83

**Bearing**

1. Check the bearing for wear or damage.


Fig. 7-84



2. Replace armature bearing if defective.

- (1) Remove the bearing with SST.  
SST [09286-46011]

Fig. 7-85



- (2) Replace the front bearing, and drive in the rear bearing with SST.  
SST [09285-76010]


## ASSEMBLY

## — Note —

When assembling, lubricate the bearings and gears with high temperature grease.

Assemble the parts in the numerical order shown in the figure.

Fig. 7-86



1. Field Frame
2. Armature
3. Brush Holder
4. End Cover
5. Felt Seal
6. Field Frame & Armature

7. Plunger Return Spring
8. Steel Ball
9. Clutch & Idler Gear
10. Starter Housing
11. Bolt
12. Through Bolt

Use high temperature grease to lubricate bearings and gears in the places shown in the figure below.

Fig. 7-87





Fig. 7-88



Fit four brushes into the brush holder, using care not to damage them.

— Note —


Check to see that the (+) lead wires are not grounded.

Fig. 7-89




Match the protrusion of the yoke core with the starter housing notch.

Fig. 7-90




Apply grease and insert the ball into the clutch shaft hole.

Fig. 7-91



Install the idler gear roller bearing in the direction shown in the figure.

Fig. 7-92



### PERFORMANCE TEST (NO-LOAD)

Connect the starter to a battery. If the starter shows smooth and steady rotation with the pinion jumping out and drawing less than specified current, it is satisfactory.

**Specified current:**

**Less than 90 A at 11.5V**

